

# VENTURE HEAT GRAND TOURING SERIES

## Wireless Controller Module User's Guide

VENTURE HEAT introduces the **Grand Touring Series** featuring the industry's **first** WIRELESS-REMOTE CONTROL to be used on **your motorcycle's handle bar**. The system was designed for **The Grand Touring Heated Jacket Liner** (standard) and optional for the **Grand Touring Heated Vest** (optional). Now you can control the heat of your gear conveniently and safely from your motorcycle's handlebar.

### **INSTALLATION**

1. **Unscrew** the knob at the bottom of the mounting bracket.
2. Ensure the **UP arrow is facing upward**.
3. **Stretch** mounting bracket over your bike's handlebars. (Add the self-adhesive padding as needed.)
4. **Screw** the knob back in until the brackets holds firm.
5. **Slide** the wireless remote down the flat side of the mount until it slides into place. To ensure the remote is mounted properly, make sure you hear a **"CLICK"** sound as it enters the mount.
6. **To remove** the controller from the bracket, **press both sides of the bracket** and slide the controller off the bracket.

### **OPERATION**

1. **Insert** the WIRELESS TRANSMITTER into the receiving port on top of the POWER BOX- located in the lower front left side inside the vest or jacket. (**DO NOT PLUG USB DEVICES INTO PORT, THIS CAN CAUSE SEVERE DAMAGE TO YOUR DEVICE**)
2. To prevent battery drain **check to see that your heated gear is connected to the vehicle's power source** through the BATTERY HARNESS, and the vehicle is turned on.
3. **PRESS the power button** to turn the WIRELESS REMOTE on. The remote will beep, and the button on your jacket or vest will turn RED (High setting)
4. To change settings, **press the button** again for YELLOW (medium), GREEN (low), and finally, OFF.
5. **After few seconds**, the WIRELESS CONTROLLER **will switch over to SLEEP MODE** to save battery power. To re-activate press the button on the WIRELESS CONTROLLER. The LED LIGHT will remain on the previous setting for your jacket or vest, to change simply **press the button to cycle through to the setting you need**.

### **SPECIAL NOTE**

1. The WIRELESS CONTROLLER may be used in conjunction with the ONBOARD CONTROLLER that was built directly onto the jacket/vest.
2. Remove & store TRANSMITTER and WIRELESS CONTROLLER when not in use.
3. The system was designed for water resistance, do not submerged under water.
4. The WIRELESS CONTROLLER & WIRELESS TRANSMITTER were paired & tested at the factory. Contact Customer Service if you are not able to get the pairing to work or needs replacement. [service@ventureheat.com](mailto:service@ventureheat.com)